

Using Jenvey injector port plugs



- 1) Push plug firmly into 13.9 to 14mm hole with the bolt facing outwards
- 2) Using a screw driver handle type 8mm socket driver, press down firmly and tighten.
- 3) The correct torque is approximately 2Nm

2NM is about 80% for the maximum that can be achieved with the screw drive type handle (no T-bar)

A rail across the top will make the fixing fully secure as will gluing down the outside once plugs tightened into place

