
## TPAK-5\_WEB -



**Engineered to win** 



WHEN FITTING A TPAK3\_2 AND TPAK 5-1 TO YOUR THROTTLE BODY, IT IS RECOMMENDED TO PUT A SMALL AMOUNT OF LOCTITE 243 TO THE THREADS TO SECURE THE BOLTS IN PLACE AND ONCE THE BOLTS ARE THREADED IN, TORQUE TO 0.8NM.

TO SECURE THE TPAK 3\_2 IN PLACE, SLIDE THE FITTING OVER THE SPINDLE END SO THAT THE TOP GRUB SCREW THREADS ARE PERPENDICULAR WITH THE SPINDLE FLAT. IT IS RECOMMENDED THAT A SMALL AMOUNT OF LOCTITE 243 IS APPLIED TO THE GRUB SCREWS, THEN THREAD IN UNTIL TIGHT.

Frame: 1 of 1
Version: 1

Tel 01746 768810

© JENVEY DYNAMICS LTD. 2021

Web WWW.JENVEY.CO.UK